



Temperaturmessumformer-Serie 6 mm  
**JUMO dTRANS T08 xx**

#### **Verlinkung zu den einzelnen Typenblättern**

707101 – JUMO dTRANS T08 01 – Eco-Thermoelementmessumformer (J, K)

707102 – JUMO dTRANS T08 02 – Eco-Messumformer (Pt100)

707111 – JUMO dTRANS T08 11 – Thermoelementmessumformer (J, K)

707112 – JUMO dTRANS T08 12 – Messumformer (Pt100)

707113 – JUMO dTRANS T08 13 – HART®-Messumformer (Pt100, J, K)

707114 – JUMO dTRANS T08 14 – Universalmessumformer

707131 – JUMO dTRANS T08 31 – Zweidrahtmessumformer (Pt100, J, K)

707133 – JUMO dTRANS T08 33 – Zweidrahtmessumformer (Pt100)

707137 – JUMO dTRANS T08 37 – Zweidraht-HART®-Messumformer (Pt100, J, K)

707189 (TN: 00697612) – JUMO dTRANS T/S08 PCU – Versorgungsklemme für dTRANS T/S 08 XX



Temperature transmitter series 6 mm  
707101

**JUMO dTRANS T08 xx**

[Link to the individual data sheets](#)

707101 – JUMO dTRANS T08 01 – Eco thermocouple transmitter (J, K)

707102 – JUMO dTRANS T08 02 – Eco transmitter (Pt100)

707111 – JUMO dTRANS T08 11 – Thermocouple transmitter (J, K)

707112 – JUMO dTRANS T08 12 – Transmitter (Pt100)

707113 – JUMO dTRANS T08 13 – HART® transmitter (Pt100, J, K)

707114 – JUMO dTRANS T08 14 – Universal transmitter

707131 – JUMO dTRANS T08 31 – Two-wire transmitter (Pt100, J, K)

707133 – JUMO dTRANS T08 33 – Two-wire transmitter (Pt100)

707137 – JUMO dTRANS T08 37 – Two-wire HART® transmitter (Pt100, J, K)

707189 (TN: 00697612) – JUMO dTRANS T/S08 PCU – Power connector unit for dTRANS T/S08 XX